# **Product Data Sheet**

# HB-198 WINDSHIELD WASHER SOLVENT

# **De-Icer & Cleaner for Automotive Windshields**

## **DESCRIPTION:**

- Formulated with special de-icing compounds to prevent freezing of windshield wipers
- Provides clearer, safer vision during freezing weather
- Contains cleaning compounds to remove dirt, oils and road film from windshields
- May be used for year round maintenance use
- Ready-to-use and should be used directly from the container
- Should be directly added to windshield washer reservoir

## For Winter Use:

Turn on auto defroster blower and activate windshield washer mechanism. Continue procedure until windshield is clear and free of ice or snow.

## For Spring and/or Summer Use:

Add 16 oz. of product concentrate to windshield washer reservoir and fill remainder with clear water.

Use to clean away road soils, dirt, insects and other debris.

## **PROPERTIES:**

Liquid Form Odor Neutral Color Blue **Toxicity** Low Wetting Ability Excellent Detergency Low Foaming None Biodegradability Yes Emulsification None **Phosphates** None Storage Stability 1 yr -29° F Cold Stability

H & B Industries, Inc.

PO Box 29838, Dallas, TX. 75229 (214)350-1984 800-466-0855 Web: hbind.com H & B Supply, Inc. 301 Crickett Lane

Temple, TX. 76501-3419 (254)985-2525

# **Product Data Sheet**

## **HB-198 PROPERTIES Continued:**

Corrosion Factor	None
Flash Point	None
Boiling Point	180° F
Vapor Pressure (mmHg)	N/A
Vapor Density (Air=1)	N/A
Solubility in Water	100%
Specific Gravity (H <sub>2</sub> O=1)	0.8921
% Volatile by Volume	99.0
Evaporation Rate (B. Acet. =1)	N/A
pH	N/A
Free Acid	None
Wt. per Gallon	7.44

## **SAFETY:**

Label use directions should be followed carefully. OSHA Material Safety Data Sheet available.

#### **CAUTION:**

**POISON:** Product contains methanol. Ingestion may result in death or cause blindness. If ingested, induce vomiting with a solution of warm salt water. Continue procedure until vomit fluid is clear. Follow with water and baking soda solution. Consult physician immediately. Keep patient warm, still and out of bright light. Apply artificial respiration if required. For skin or eye contact, flush area with clear water for 15 minutes. Seek medical attention. Keep container sealed when not in use. Dispose of empty container in an authorized landfill site.